

LIQUID BOOT[®] UltraShield P-150 INSTALLATION INSTRUCTIONS

UNDER-SLAB INSTRUCTIONS:

1. Unroll UltraShield P-150 over the area where the slab is to be poured. The UltraShield P-150 should completely cover the pour area. All joints/seams both lateral and butt should be overlapped six inches and taped using UltraShield P-Seam Tape.

NOTE: The area of adhesion should be free from dust, dirt and moisture to allow maximum adhesion of the pressure sensitive tape.

2. In the event that the UltraShield P-150 is damaged during or after installation, repairs must be made. Cut a piece of UltraShield P-150 large enough to cover any damage by a minimum overlap of six inches in all directions. Clean all adhesion areas of dust, dirt and moisture. Tape down all edges using UltraShield P-Seam Tape.

REMEMBER: If damaged, UltraShield P-150 must be repaired using the techniques outlined above.

VERTICAL WALL INSTRUCTIONS:

1. Install LIQUID BOOT[®] according to the manufacturer's installation instructions.
2. While the membrane is still tacky, install UltraShield P-150 as a protective course/vapor barrier over the applied waterproofing membrane. The use of LIQUID BOOT[®] UltraGrip may be needed to adhere the UltraShield P-150 to the membrane.
3. Supervised care must be taken during back filling against the material so that it is not damaged or punctured. If damage occurs, check the LIQUID BOOT[®] membrane for damage and patch accordingly.
4. In the event that the UltraShield P-150 is damaged during or after installation, repairs must be made. Cut a piece of UltraShield P-150 large enough to cover any damage by a minimum overlap of six inches in all directions. Clean all adhesion areas of dust, dirt and moisture. Tape down all edges using UltraShield P-Seam Tape.